





Scepter Firmware Update

1

Connect the Scepter to a wireless network with internet access. See *AML Scepter Wi-Fi Setup*.

2

Go to: **Settings** → **About Device** → **Additional system updates** → and tap **Update**:



Allow a few minutes while the Scepter downloads and installs the system update.
The Scepter will reboot on its own upon successful completion.

