



# Quick Start Guide



2190 Regal Parkway  
Euless, Texas 76040  
**800.648.4452**  
[www.amltd.com](http://www.amltd.com)



# Front and Back View



- 1 & 2:** USB Hosts (2.0) x 2
- 3:** USB-C (debug/app development only)
- 4:** DC Power supply input (5VDC)
- 5:** Ethernet + PoE (10/100)
- 6:** M4 x 10mm mounting screws (4)
- 7:** I/O cable(s) exit pathway
- 8:** Serial number
- 9:** Power switch

## 10: I/O door and screw

- Remove screw to remove I/O compartment door.
- Provides access to concealed USB Host (2.0) and headphone/Mic port
- Provides access to optional I/O board

# Mounting Options

---

## Adjustable Angle Mounting Bracket

### ACC-0794

The ACC-0794 adjustable angle bracket is designed for fast, easy mounting and allows you to choose your mounting angle (10° or 15°).



## 15° Quick Mount Wall Bracket

### ACC-0793

Quickly and easily mount the device to a wall or another flush surface at a 15° backward tilt. The bracket includes kiosk mounting hardware. A locking mechanism is also included with this bracket.



# Important!!! Power Options

---

The Firebird can utilize two power sources: An external DC power supply or Power-over-Ethernet.



## Internal Power-over-Ethernet Supply

*The unit can be powered via category 5 networking cable when used with an 802.3af compatible power injector or switch. Both network traffic and power can be sent via the same category 5 wire.*

---

## External Power Supply, 5VDC, 4A

**WARNING:** Using power supplies that are not supplied by AML for use with the Firebird unit can cause damages to the unit and WILL void all warranties. **(AML Part: PWR-7150)**



# StoreScan

---



AML's StoreScan price-checking software is a simple, yet powerful application that allows retailers of all types and sizes to offer the convenience of price verification to their customers. Eliminate the frustration of missing or incorrect pricing by offering easy, self-service functionality using any of the AML Kiosks. Checking the price of a product has never been easier.

## StoreScan Demo Barcodes



# Support & Repair Services

---



## **AML Technical Support Team**

AML technical phone support is toll-free and pain-free. Speak with a US-based AML employee trained to answer your question and do everything possible to resolve any issues that might arise.

**877-842-3990 Mon-Fri 8:00 to 5:00 CST**

If your Firebird Kiosk is in need of repairs, you may request an RMA number (Return Material Authorization) by calling **877-842-3990**, between 8:00 am and 5:00 pm, (CST) Monday-Friday.

You may also request an RMA number online at:

**<https://www.amltd.com/RMA-Request>**

# Warranty



## UPGRADE YOUR WARRANTY COVERAGE TODAY!

Do we have the coverage we need?

Extended Warranty PLUS programs provide:

- Coverage for the failure of internal and external components regardless of fault\*.
- Four (4) business-day turnaround, excluding time-in-transit.
- Standard ground shipping for device return included.

\* Does not include replacement of device.

For more information, contact AML today.

**800-648-4452**

or

[www.amltd.com/Warranty-Quote-Request](http://www.amltd.com/Warranty-Quote-Request)



## Warranty Agreements

**SVC-EWPKDT7** Extended Warranty Plus, 3-year, Firebird

## Sanitizing Your Device



The best way to clean and sanitize your AML mobile computer or kiosk is to use a diluted solution of three-parts water and one-part rubbing alcohol. Rubbing alcohol is a diluted form of isopropyl alcohol. It typically contains 70% isopropyl alcohol with the balance consisting of other denaturants. Do not use full-strength isopropyl alcohol.

Apply the solution to a soft cloth first, and then wipe all surfaces of the device.

# Copyright

---

© 2022 AML. All rights reserved.

AML reserves the right to make changes in specifications and other information contained in this document without prior notice, and the reader should in all cases consult AML to determine whether any such changes have been made. The information in this publication does not represent a commitment on the part of AML shall not be liable for technical or editorial errors or omissions contained herein; nor for incidental or consequential damages resulting from the furnishing, performance, or use of this material. This document contains proprietary information which is protected by copyright. All rights are reserved. No part of this document may be photocopied, reproduced, or translated into another language without the prior written consent of AML.



TESTED TO COMPLY  
WITH FCC STANDARDS





## NOTES


## NOTES




2190 Regal Parkway  
Euless, Texas 76040  
**800.648.4452**  
[www.amltd.com](http://www.amltd.com)

