

## **Installation Manual**






7361 Airport Fwy Richland Hills, Texas 76118

800.648.4452 www.amltd.com




#### AML ADJUSTABLE ANGLE VESA 75 BRACKET (ACC-0794)

REMOVE THE 2 BOTTOMS SCREWS, DO NOT DISCARD




## UNHOOK THE FRONT PANEL FROM REAR PANEL WITH AN UPWARD MOTION, AS SHOWN




#### BRACKET INSTALLATION: VMU IN PORTRAIT MODE


#### USE M4 SCREWS PROVIDED WITH DEVICE



#### BRACKET INSTALLATION: VMU IN LANDSCAPE MODE



#### PLUG IN POWER (5V), AND OTHER PERIPHERALS AS NEEDED



WIRE THE DC CABLE PROVIDED WITH CONVERTER KIT TO THE +VOUT (RED WIRE)

AND -VOUT (BLACK WIRE) OF THE CONVERTER


## YOU MUST USE A DC POWER CONVERTER KIT TO CONVERT VEHICLE POWER (12 OR 48V) DOWN TO THE 5V REQUIRED BY THE VMU

If the vehicle's power system is:	Use this DC Power Converter
	Kit (converter + cable):
9 to 36 VDC	PWR-5V4ADC24-06
18 to 75 VDC	PWR-5V4ADC48-06




## SECURE AML ACC-0794 REAR BRACKET TO A VEHICLE MOUNT INTERFACE (EXAMPLE SHOWN HERE)


## USE #8 OR M4 HARDWARE (MOUNT AND HARDWARE NOT INCLUDED)



### ACC-0794's REAR BRACKET FEATURES AMP, GANG, AND VESA 75 PATTERNS, IT CAN ALSO BE SECURED WITH STRAPING USING THE PROVIDED SIDE SLOTS




# HOOK THE DEVICE AND FRONT BRACKET ONTO THE REAR BRAKET, AS SHOWN. RE-INSTALL THE TWO BOTTOM SCREWS AT DESIRED ANGLES (0 – 10 – 15 DEGREES POSITIONS AVAILABLE)



## RECOMMENDED HARDWARETO SECURE FIREBIRD VMU TO A FORKLIFT. THIS HARDWARE PROVIDES VIBRATION DAMPENING

RAM® Double Socket Arm - C Size Part#:RAM-201U-B

RAM® Round Plate with Ball - C Size Part#:RAM-202U



## **Support & Repair Services**



#### **AML Technical Support Team**

AML technical phone support is toll-free and painfree. Speak with a US-based AML employee trained to answer your question and do everything possible to resolve any issues that might arise.

877-842-3990 Mon-Fri 8:00 to 5:00 CST

If your Firebird VMU is in need of repairs, you may request an RMA number (Return Material Authorization) by calling **877-842-3990**, between 8:00 am and 5:00 pm, (CST) Monday-Friday.

You may also request an RMA number online at:

https://www.amltd.com/RMA-Request