

Regulatory Information

All American Microsystems, Ltd. devices are designed to be compliant with rules and regulations in locations they are sold and will be labeled as required. Any changes or modifications to American Microsystems, Ltd. equipment, not expressly approved by American Microsystems, Ltd., could void the user's authority to operate the equipment.

Power Supply

Use only an American Microsystems, Ltd. approved Power Supply, output rated 12 VDC and minimum 5A. The Power Supply is certified to EN60950.

Disclaimer

American Microsystems, Ltd. reserves the right to make changes in specifications and other information contained in this document without prior notice, and the reader should in all cases consult American Microsystems, Ltd. to determine whether any such changes have been made. The information in this publication does not represent a commitment on the part of American Microsystems, Ltd.

American Microsystems, Ltd. shall not be liable for technical or editorial errors or omissions contained herein; nor for incidental or consequential damages resulting from the furnishing, performance, or use of this material.

This document contains proprietary information that is protected by copyright. All rights are reserved. No part of this document may be photocopied, reproduced, or translated into another language without the prior written consent of American Microsystems, Ltd.

FC FCC Declaration of Conformity
Product Name: 4-Position Battery Charger
Model Number: ACC-7037

Radio Frequency Interference Requirements

This equipment complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This equipment may not cause harmful interference, and (2) this equipment must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a residential environment. This equipment generates uses and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If you determine the equipment does cause harmful interference to radio or television reception (this may be determined by monitoring the interference while turning the equipment off and on), you are encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio or TV technician for help.

Radio Frequency Interference Requirements - Canada

This Class A digital apparatus complies with Canadian ICES-003.
Cet appareil numérique de la classe A est conforme à la norme NMB-003 du Canada.

Marking and European Economic Area (EEA)

CE Products intended for sale within the European Union are marked with the CE mark which indicates compliance to applicable Directives and European Norms (EN), as follows. Amendments to these Directives or EN's are included.

- Electromagnetic Compatibility Directive 89/336/EEC
- Low Voltage Directive 73/23/EEC



Safety NOM / NYCE-NOM-001-SCFI-1993
Electronic Apparatus: Household electronic apparatus powered by different sources of electrical energy.

© American Microsystems, Ltd.
2190 Regal Parkway • Euless, TX 76040
Phone 817.571.9015 • Fax 817.571.6176

4-Position Battery Charger



User's Guide

© 2009 American Microsystems Ltd.
Effective date: February 2009
Website: www.amltd.com

Introduction

The ACC-7037 4-Position Battery Charger charges up to four Li-Ion batteries. This allows batteries to be quickly changed at the end or beginning of work-shifts, assuring the user a freshly charged battery. The charging time for a fully depleted battery pack is approximately 2 hours.

About This Guide

This guide provides instruction on setting up and using the ACC-7037 4-Position Battery Charger.

Set Up

Setting up the charger includes unpacking, connecting the power cable, and placing the charger on a tabletop.

Unpacking the Charger

The shipping box includes the following:

- One ACC-7037 4-Position Battery Charger
- One PWR-7160 Power Supply
- One 120 VAC Power Cable (or country specific)
- This User's Guide.

If any parts are missing or damaged, contact your authorized Customer Support Representative immediately. Save the shipping box for storing or shipping.

Connecting the Power

The PWR-7160 power supply is included with the ACC-7037 4-Position Battery Charger. If a country-specific AC power supply is required, please contact your authorized Customer Support Representative.

Use only an American Microsystems, Ltd. approved power supply; output rated 12 VDC and a minimum of 5 Amps. The power supply connects to the ACC-7037 by a 2.1mm x 5.5mm barrel connector, center positive.

To connect power to the charger:

1. Connect one end of the Power Supply Cable to the Power Connector on the side of the charger.
2. Connect the other end of the Power Supply AC to a standard electrical outlet.
3. The indicator LEDs should turn GREEN to indicate that power is available.

Charging

Turn OFF the terminal or computer when removing the battery. Place the battery with metal contacts facing downward into an open charging position. The battery begins to charge as soon as it is inserted.

Indicator Lights

LED Color	Description
Off	No power supplied to charger.
Green	If no battery is present in the charger, green indicates that there is power available. If a battery is present in the charging position, green indicates that the battery is fully charged.
Red	Battery is present in the terminal charger and the battery is being charged.

Troubleshooting

Symptom	Cause	Suggested Action
LED does not light when the terminal charger is powered on.	Charger is not receiving power.	Make sure the power supply is securely connected and receiving power.
LED stays green when the battery is inserted.	Terminal is not seated firmly in the terminal charger, or the battery is not properly installed in the terminal.	Make sure the battery is properly seated. Second, test battery in an approved AML terminal/computer. Battery may be defective.
	Battery is charged.	Normal status.
LED stays red for more than 4 hours.	Battery faulty and can not be charged.	Replace battery with an AML approved battery.